

## EasyGate instruction manual for keyed exit button

### Installation:

1. Locate a suitable place up to 30 meters from the gate to place your exit button. It is weather proof so out in the rain is fine. We generally recommend on a post on the right hand side of the driveway (when driving out of the property) so vehicles can roll their window down to leave. Alternatively if you don't need the exit button apart from for pedestrians or emergency find a location where it's more discreet.
2. Undo the 4 screws in the corners and remove the top half (Image 1).
3. Inside you will see a wire between 2 of the 4 terminals and the other 2 terminals will be blank. Place your 2 connecting wires into the 2 empty terminals. (Image 2)
4. Connect the other ends of the cable to your 2 activation points on the control board. Do not have power going to the board when doing this in case you short circuit the control board.

Once you have connected the control board end press the button to see if it activates. If it fails to do so turn the lock using the key provided.

Note: Keep in mind that you can lock the exit button without a key but you cannot unlock it without the key.